

# AlarmMini

Короткий посібник • Українська

UA

## Ваша мапа. Ваш ритм.

Стан тривоги на LED-мапі України. Керування з телефона, оновлення через USB.

### 01 Підключіть до Wi-Fi

Увімкніть мапу. На телефоні підключіться до **AlarmMap-Setup-XXXXXX** без пароля. Відкрийте **http://192.168.4.1**, оберіть домашню мережу **2,4 ГГц** і збережіть її пароль. Поверніться до домашнього Wi-Fi.

### 02 Відкрийте панель

Відскануйте QR або відкрийте адресу з етикетки мапи. Введіть пароль адміністратора з етикетки. Адресу й пароль також можна переглянути на сайті інсталятора, підключивши плату через USB.

### 03 Оберіть мову та місцевий час

**UA / EN** перемикає мову. У **Нічний режим** → **Часовий пояс** знайдіть країну/місто або натисніть **Визначити з браузера**. Для подарунка оберіть місце одержувача. Літній/зимовий час змінюється автоматично. Натисніть **Зберегти**.

### 04 Налаштуйте під себе

**Кольори**: денна/нічна яскравість і кольори станів. **Нічний режим**: час початку та завершення. **MQTT**: основний і резервний канали. Початковий профіль уже налаштований. Перед змінами зробіть **Експорт** JSON; для повернення використайте **Імпорт**.

### 05 Оновлюйте зі збереженням

На комп'ютері відкрийте сайт нижче в **Chrome або Edge**. Підключіть плату USB-кабелем із даними, виберіть модель та оновлення зі збереженням налаштувань. Не від'єднуйте USB до завершення. Після цього оновіть сторінку мапи.

Не відкривається панель? Перевірте, що телефон і мапа в одній Wi-Fi мережі; спробуйте IP-адресу з інсталятора. Немає актуальних даних? Перевірте Wi-Fi / MQTT та інтернет.

Мапа є допоміжним індикатором. Орієнтуйтеся на офіційні сповіщення про безпеку.



Сайт та оновлення  
[alarmmini.vercel.app](http://alarmmini.vercel.app)  
[Допомога в Telegram](#)

# AlarmMini

Quick user guide • English

EN

## Your map. Your rhythm.

Ukraine alerts on your LED map. Phone controls, USB updates.

### 01 Connect to Wi-Fi

Power on the map. On your phone, join **AlarmMap-Setup-XXXXXX** without a password. Open **http://192.168.4.1**, choose your home **2.4 GHz** network and save its password. Rejoin your home Wi-Fi.

### 02 Open the dashboard

Scan the QR code or open the address on the map's label. Enter the admin password from the label. You can also view the address and password on the installer website with the board connected by USB.

### 03 Choose language and local time

**UA / EN** changes the language. Under **Night mode** → **Time zone**, search for a country/city or select **Use browser time zone**. For a gift, choose the recipient's location. Summer/winter time changes automatically. Select **Save**.

### 04 Make it yours

**Colors**: day/night brightness and state colors. **Night mode**: start and end times. **MQTT**: primary and fallback sources. The initial profile is already configured. Before editing, use **Export** to save a JSON backup; use **Import** to restore it.

### 05 Update and keep your settings

On a computer, open the website below in **Chrome or Edge**. Connect the board with a USB data cable, choose the board model and update while preserving settings. Keep USB connected until the update finishes. Then refresh the map's page.

Dashboard unavailable? Connect the phone and map to the same Wi-Fi; try the IP address shown by the installer. Stale data? Check Wi-Fi / MQTT status and the internet connection.

The map is a supplementary display. Always follow official emergency notifications.



Website & updates  
[alarmmini.vercel.app](http://alarmmini.vercel.app)  
[Telegram support](#)